



## FLEXIBLE CLAMP METER KEW 2204R/2210R



## KEW 2204R/2210R Specifications

	KEW2204R	KEW2210R	
AC A (RMS)			
Range	4.000/40.00/400.0A	30.00/300.0/3000A	
Accuracy	±3%rdg±5dgt[45-500Hz] (At the center of the circle for	±3%rdg±5dgt[45-500Hz] (At the center of the circle formed by the flexible sensor)	
Crest factor (CF)		Full scale CF<1.6, half scale<3.2 Effective input crest values are $\sqrt{2}$ times of the max values of each range.	
Conductor size	φ70mm max.	$\phi$ 150mm max.	
Influence of Conductor position	Additional ±2%(max.)dependence the distance from the center po	ding on Additional $\pm 3\%$ (max.) depending on the distance from the center position	
Overload protection	500A AC for 10 seconds	5000A AC for 10 seconds	
Applicable standard	CAT IV 600V / CAT III 1000V	IEC 61010-1, IEC 61010-2-032 CAT № 600V / CAT III 1000V Pollution degree 2 IEC 61326-1(EMC) , IEC 60529 IP40 , EN50581(RoHS)	
Operating temperat & humidity	perature 0 - +50°C,less than 80% RH (without condensation)		
Storage temperatur & humidity	-10 - +60℃,less than 70% RI	-10 - +60℃,less than 70% RH (without condensation)	
Power source		R03 / LR03(AAA)(1.5V)×2  **Continuous measuring time: approx.120hours (Auto power off: approx.15 minutes)	
Dimensions	120(L)×70(W)×26(D): Displa φ5.5mm approx.: Cable dia 1.8m approx.: Cable length		
Weight	200g approx. (including batte	eries) 300g approx. (including batteries)	
Included Accessorie	9174 (Carrying case) LR03(AAA)×2, Insruction ma	anual	

**Operating Instructions** 

To open this flex sensor, disconnect the joint by pulling to the right.

Confirm that the joint connector on the flex sensor is firmly. Clamp onto one conductor only to the illustration above.






















Please read the "Safety Warnings" in the instruction manual supplied with the instrument thoroughly and completely Safety Warnings: If the instruction main supplied with the instrument thoroughly and completely

Safety Warnings: If the instruction main supplied with the instrument thoroughly and completely

Failure to follow the safety rules can cause fire, trouble, editorial shock in the instrument thoroughly and completely

The safety Warnings: If the instruction main supplied with the instrument thoroughly and completely

Safety Warnings: If the instruction main supplied with the instrument thoroughly and completely

Safety Warnings: If the instruction main supplied with the instrument thoroughly and completely

Safety Warnings: If the instruction main supplied with the instrument thoroughly and completely

Safety Warnings: If the instrument is the instrument thoroughly and completely

Safety Warnings: If the instrument is the instrument thoroughly and completely

Safety Warnings: If the instrument is the instrument is the instrument thoroughly and completely

Safety Warnings: If the instrument is the instrument is the instrument thoroughly and completely

Safety Warnings: If the instrument is the instrument is the instrument in the instrument in the instrument is the instrument in the instr to operate the instrument on a correct power supply and voltage rating marked on each instrument.

## For inquires or orders:



2-5-20, Nakane, Meguro-ku, Tokyo, 152-0031 Japan Phone:+81-3-3723-0131 Fax:+81-3-3723-0152 E-mail:info-eng@kew-ltd.co.jp

http://www.kew-ltd.co.jp